

Manuale d'uso - Efficienza Energetica / User Manual - Energy Efficiency / Manuel de l'utilisateur - L'efficacité énergétique / Handbuch - Energieeffizienz / Handboek - Energie-efficiëntie Manual - Eficiencia Energética / Manual - Eficiência Energética / Manuell - Energieeffektivitet / Manuell - Energieeffektivitet / Manuaalinen - Energy Efficiency / Manual - Energieeffektivitet Руководство - Энергоэффективность / Käsiiraamat - Energiatõhususe / Rokasgrāmata - Energieeffektivitātes

Table with 12 columns (PF, IT, EN, FR, DE, NL, ES, PT, SV, NO, FI, DK, RU, ET, LV) and 20 rows of technical specifications and user instructions for a hood model 110.0260.728 P1171. The table includes performance metrics (AEC, EEC, FDE, FDEC, LE, LEC, GFE, GFEC, Qmin, Qmax, Qboost, SPE, SPEmax, SPEboost, P0, Ps), energy consumption (PI), efficiency indices (EE, Qbep, Wbep, WL, Emiddle, Lwa), and safety instructions (CONSIGLI PER IL RISPARMIO ENERGETICO, CONSEILS POUR L'ECONOMIE ENERGETIQUE, RATSCHELAGE ZUR ENERGIEESPARNUNG, TIPS VOR ENERGIEBESPARUNG, CONSEJOS PARA EL AHORRO DE ENERGIA, CONSELHOS PARA POUPAR ENERGIA, RÅD FÖR ENERGIBESPARING, ENERGIASAÄSTUNO UVOJA, TIPS TIL ENERGIBESPARELSE, РЕКОМЕНДАЦИИ ПО ЭКОНОМИИ ЭНЕРГИИ, ENERGIASAÄSTÜNÖ ANDEN, PADOMI ENERGIJAS TAUPŠANAI, Norme di riferimento, Normative references, Normes de référence, Referenznormen, Normas de referencia, Normas de referência, Referensstandarder, Referensstandarder, Vitnormit, Referencestandarder, Normatīvās dokumenti, Normatīvities).

