

Manuale d'uso - Efficienza Energetica / User Manual - Energy Efficiency / Manuel de l'utilisateur - L'efficacité énergétique / Handbuch - Energieeffizienz / Handboek - Energie-efficiëntie Manual - Eficiencia Energética / Manual - Eficiência Energética / Manuell - Energieeffektivitet / Manuell - Energieeffektivitet / Manuaalinen - Energy Efficiency / Manual - Energieeffektivitet Руководство - Энергоэффективность / Käsiiraamat - Energiatõhususe / Rokasgrāmata - Energieeffektivitātes

Table with 13 columns: Label (S, M, AEC, EEC, FDE, FDEC, LE, LEC, GFE, GFEC, Qmin, Qmax, Qboost, SPEmin, SPEmax, SPEboost, P0, Ps, F, EEL, Qbep, Pbp, Qmax, Wbep, WL, Emiddle, Lwa), PF (FABER), IT, EN, FR, DE, NL, ES, PT, SV, NO, FI, DK, RU, ET, LV. Rows include technical specifications like Annual Efficiency Consumption (AEC), Fluid Dynamic Efficiency (FDE), Lighting Efficiency (LE), Grease Filtration Efficiency (GFE), Air Flow (Q), Acoustic Power Emission (SPE), Power Consumption (P), Energy Efficiency Index (EEI), and Sound Power Level (Lwa).

